

*Nick Jackson Co. Inc.*

*Yacht Davit Systems*

*TRANSOM DAVIT SERIES*

17725 NE 65th St. Suite A 175 Redmond WA 98052

ph 425 481 1381 fax 425 882 2054

www.nickjacksonco.com njcdavits@aol.com

## INSTRUCTIONS FOR DETERMINING SLOPE OF DECK AT STANDPIPE LOCATION

- 1 Make sure boat is trim port to starboard (level).
- 2 Determine location of standpipe on deck.
- 3 Using tape, mark standpipe center line on deck.
- 4 Lay 2 foot level across mark on deck, port to starboard (see Diagram) and make level.
- 5 Measure distance at Point (A) and record.

### Example

If (A) = 2.5 inches, deck slope will be 2.5" inches in 2 feet.

